

THIN-LINE™ TL-080B METRIC WELD HEADS

USER MANUAL



Copyright © 2002 – 2024 Amada Weld Tech

The engineering designs, drawings and data contained herein are the proprietary work of Amada Weld Tech and may not be reproduced, copied, exhibited or otherwise used without the written authorization of Amada Weld Tech.

Printed in the United States of America.

REVISION RECORD

Revision	EO	Date	Basis of Revision
A	19146	01/02	Original edition.
B	21776	05/08	Update to Miyachi Unitek logo, and added new CAUTION information.
C	42860	11/13	Update to Miyachi America name and logo.
D	43481	11/14	Update to Amada Miyachi America name and logo.
E	43866	08/15	Updated to Amada Miyachi America format.
F	44244	05/16	Updated contact information
G	45853	04/20	Update Company Name (Amada Weld Tech) + Model Names
H	47210	01/24	Update Manual Title

FOREWORD

Thank you for purchasing an Amada Weld Tech TL-080B Metric Thin-Line Weld Head.

Upon receipt of your equipment, please thoroughly inspect it for shipping damage before its installation. Should there be any damage, please immediately contact the shipping company to file a claim, and notify us at:

Amada Weld Tech Inc.
1820 South Myrtle Avenue
Monrovia, California 91016
Phone: (626) 303-5676
FAX: (626) 358-8048
E-mail: info@amadaweldtech.com

The purpose of this manual is to supply operating, maintenance and service personnel with the information needed to properly and safely operate and service the TL-080B Metric Thin-Line Weld Heads.

We have made every effort to ensure that the information in this manual is accurate and adequate. Should questions arise, or if you have suggestions for improvement of this manual, please contact us at the above location/numbers. The contents of this manual are subject to change without notice.

Amada Weld Tech is not responsible for any loss or injury due to improper use of this product.

This Manual covers the following Metric Weld Head models:

Original Model Name		Current Model Name	Basic Part Number
80MF	→	TL-080B-F/M	2-142-xx
88MF	→	TL-088B-F/M	2-88MF-00x
88MA-EZ	→	TL-088B-MA-EZ	2-88MA-EZ-00x

Legacy Products included in this Manual:

84MF
86MF
80MA-EZ
84MA-EZ
86MA-EZ

Contents

	Page
Chapter 1. System Description	1-1
Section I. Features	1-1
Overview	1-1
Preset Firing Force	1-1
Up and Down Stops	1-2
Electrodes	1-2
Insulation	1-2
Welding Cables	1-2
Footpedal Actuation	1-2
Air Actuation	1-2
Section II. System Components	1-3
Model TL-080B-F/M (and legacy model 80MA-EZ)	1-3
Legacy Models 84MF and 84MA-EZ	1-3
Legacy Model 86MF and 86MA-EZ	1-4
Model TL-088B-F/M and TL-088B-MA-EA	1-4
Section III. Welding Capabilities	1-5
Series Welding	1-5
Step Welding	1-5
Section IV. Operating Controls	1-6
TL-080B Metric Air Actuation Specifications	1-6
Air Cylinders	1-6
Footswitches	1-6
Chapter 2. Installation	2-1
Section I. Introduction	2-1
Overview	2-1
Mounting Posts	2-1
Mounting Tube	2-1
Dual-Post	2-2
Channeled-Post	2-2
Section II. Weld Head Installation	2-3
Overview	2-3
Typical Installation	2-3
Model TL-080B-F/M (and legacy model 86MF) CP Footpedal Installation	2-7
Model TL-088B-F/M (and legacy model 84MF) MSP Footpedal Installation	2-8
Model TL-088B-MA-EZ (and legacy models 80MA-EZ, 84MA-EZ, 86MA-EZ) Air	
Connection	2-9
Optics	2-10
Section III. Connect Weld Cables	2-11
Weld Cables and Energy Losses	2-11
Connect Cables to Head	2-11

Contents (continued)

Page

Section IV. Install Electrodes	2-13
Model TL-080B (and legacy model 84M)	2-13
Model TL-088B	2-13
Legacy Model 86M -- Unibond Electrodes	2-14
Legacy Model 86M -- Unitip Electrodes	2-15
Section V. Install Optional Equipment	2-16
Model TL-088B-F/M -- Install DFS/88 Series Firing Switch Junction Box	2-16
Connect Optional Hall Effect Limit Switch	2-16
Chapter 3. Operating Instructions	3-1
Section I. Getting Started	3-1
Installation Checklists	3-1
Welding Force Theory	3-2
Troubleshooting	3-2
Reflow Soldering Force	3-4
Section II. Model TL-088B-MA-EZ Air-Actuated Head Setup	3-5
Section III. Model TL-088B-F/M Manually-Actuated Head Setup	3-7
Section IV. Model TL-080B-F/M (and legacy models 84MF and 86MF) Manually-Actuated Head Setup	3-9
Section II. Legacy Models 80MA-EZ, 84MA-EZ, and 86MA-EZ Air-Actuated Head Setup	3-11
Chapter 4. User Maintenance	4-1
Section I. General Maintenance	4-1
Inspection	4-1
Lubrication	4-1
Section II. Standard Resistance Welding Electrode Cleaning	4-1
Section III. Unitip Electrode Maintenance	4-2
Section IV. Tare Spring Adjustment - Model TL-080B, TL-088B (and legacy model 86M)	4-4
Appendix A. Technical Specifications	A-1
Low-Force Weld Heads: 2.2 to 89N (0.25 to 20 Lbs)	A-1
Low-Force <i>EZ-AIR</i> Weld Heads: 2.2 to 89N (0.25 to 20 Lbs)	A-2
High-Force Weld Heads: 18 to 178N (4 to 40 Lbs)	A-3
High-Force <i>EZ-AIR</i> Weld Heads: 18 to 178N (4 to 40 Lbs)	A-4

LIMITED WARRANTY

GENERAL TERMS AND CONDITIONS FOR THE SALE OF GOODS

1. Applicability.

(a) These terms and conditions of sale (these “**Terms**”) are the only terms which govern the sale of the goods (“**Goods**”) by Amada Weld Tech Inc. (“**Seller**”) to the buyer identified in the Sales Quotation and/or Acknowledgment (as each defined below) to which these Terms are attached or incorporated by reference (“**Buyer**”). Notwithstanding anything herein to the contrary, if a written contract signed by authorized representatives of both parties is in existence covering the sale of the Goods covered hereby, the terms and conditions of said contract shall prevail to the extent they are inconsistent with these Terms.

(b) The accompanying quotation of sale (the “**Sales Quotation**”) provided to Buyer, and/or sales order acknowledgement (“**Acknowledgement**”) and these Terms (collectively, this “**Agreement**”) comprise the entire agreement between the parties, and supersede all prior or contemporaneous understandings, agreements, negotiations, representations and warranties, and communications, both written and oral. For clarification, after the Acknowledgement is received by Buyer, the order for Goods is binding and cannot be cancelled by Buyer for any reason and the full purchase price amount set forth in the Acknowledgement shall be due and payable by Buyer to Seller pursuant to the payment schedule set forth in the Acknowledgement unless otherwise agreed to in writing by Seller. All terms and conditions contained in any prior or contemporaneous oral or written communication which are different from, or in addition to, the terms and conditions in this Agreement are hereby rejected and shall not be binding on Seller, whether or not they would materially alter this Agreement. These Terms prevail over any of Buyer’s terms and conditions of purchase regardless whether or when Buyer has submitted its purchase order or such terms. Fulfillment of Buyer’s order does not constitute acceptance of any of Buyer’s terms and conditions and does not serve to modify or amend these Terms. Notwithstanding anything herein to the contrary, all orders for Goods must be for a minimum purchase price of \$100 or such orders will be rejected by Seller.

2. Delivery.

(a) The Goods will be delivered within a reasonable time after Seller provides Buyer the Acknowledgment, subject to availability of finished Goods. Seller will endeavor to meet delivery schedules requested by Buyer, but in no event shall Seller incur any liability, consequential or otherwise, for any delays or failure to deliver as a result of ceasing to manufacture any product or any Force Majeure Event. Delivery schedules set forth in the Acknowledgment are Seller’s good faith estimate on the basis of current schedules. In no event shall Seller be liable for special or consequential damages resulting from failure to meet requested delivery schedules.

(b) Unless otherwise agreed in writing by the parties in the Acknowledgement, Seller shall deliver the Goods to Seller’s plant in Monrovia, CA, USA (the “**Shipping Point**”) using Seller’s standard methods for packaging and shipping such Goods. Buyer shall take delivery of the Goods within three (3) days of Seller’s written notice that the Goods have been delivered to the Shipping Point. Buyer shall be responsible for all loading costs (including freight and insurance costs) and provide equipment and labor reasonably suited for receipt of the Goods at the Shipping Point. Seller shall not be liable for any delays, loss or damage in transit.

(c) Seller may, in its sole discretion, without liability or penalty, make partial shipments of Goods to Buyer, if applicable. Each shipment will constitute a separate sale, and Buyer shall pay for the units shipped whether such shipment is in whole or partial fulfillment of Buyer’s purchase order.

(d) If for any reason Buyer fails to accept delivery of any of the Goods on the date fixed pursuant to Seller’s notice that the Goods have been delivered at the Shipping Point, or if Seller is unable to deliver the Goods at the Shipping Point on such date because Buyer has not provided appropriate instructions, documents, licenses or authorizations: (i) risk of loss to the Goods shall pass to Buyer; (ii) the Goods shall be deemed to have been delivered; and (iii) Seller, at its option, may store the Goods until Buyer picks them up, whereupon Buyer shall be liable for all related costs and expenses (including, without limitation, storage and insurance).

3. Non-delivery.

(a) The quantity of any installment of Goods as recorded by Seller on dispatch from Seller’s place of business is conclusive evidence of the quantity received by Buyer on delivery unless Buyer can provide conclusive evidence proving the contrary.

(b) Seller shall not be liable for any non-delivery of Goods (even if caused by Seller’s negligence) unless Buyer gives written notice to Seller of the non-delivery within three (3) days of the date when the Goods would in the ordinary course of events have been received.

(c) Any liability of Seller for non-delivery of the Goods shall be limited to (in Seller’s sole discretion) replacing the Goods within a reasonable time or adjusting the invoice respecting such Goods to reflect the actual quantity delivered.

4. Shipping Terms. Unless indicated otherwise in the Acknowledgment, Delivery shall be made EXW (Incoterms 2010), Shipping Point, including without limitation, freight and insurance costs. If no delivery terms are specified on the Acknowledgement, the method of shipping will be in the sole discretion of Seller. Unless directed in writing otherwise by Buyer, full invoice value will be declared for all shipments.

5. Title and Risk of Loss. Title and risk of loss passes to Buyer upon delivery of the Goods at the Shipping Point. As collateral security for the payment of the purchase price of the Goods, Buyer hereby grants to Seller a lien on and security interest in and to all of the right, title and interest of Buyer in, to and under the Goods, wherever located, and whether now existing or hereafter arising or acquired from time to time, and in all accessions thereto and replacements or modifications thereof, as well as all proceeds (including insurance proceeds) of the foregoing. The security interest granted under this provision constitutes a purchase money security interest under the California Commercial Code.

6. Amendment and Modification. These Terms may only be amended or modified in a writing which specifically states that it amends these Terms and is signed by an authorized representative of each party.

TL-080B METRIC THIN-LINE™ WELD HEADS

7. Inspection and Rejection of Nonconforming Goods.

(a) Buyer shall inspect the Goods within two (2) days of receipt ("**Inspection Period**"). Buyer will be deemed to have accepted the Goods unless it notifies Seller in writing of any Nonconforming Goods during the Inspection Period and furnishes such written evidence or other documentation as required by Seller. "**Nonconforming Goods**" means only the following: (i) product shipped is different than identified in Buyer's Acknowledgement; or (ii) product's label or packaging incorrectly identifies its contents. Notwithstanding the foregoing, for shipped Goods that require field installation, the "re-verification" terms in the Acknowledgement shall apply and for custom installations, the inspection and verification shall take place at Buyer's site immediately after the installation is completed.

(b) Seller will only accept Nonconforming Goods that are returned under Seller's Return Material Authorization procedures then in effect ("**RMA**"). Buyer shall obtain a RMA number from Seller prior to returning any Nonconforming Goods and return the Nonconforming Goods prepaid and insured to Seller at 1820 South Myrtle Avenue, Monrovia, CA 91016 or to such other location as designated in writing by Seller for the examination to take place there. If Seller reasonably verifies Buyer's claim that the Goods are Nonconforming Goods and that the nonconformance did not developed by use from Buyer, Seller shall, in its sole discretion, (i) replace such Nonconforming Goods with conforming Goods, or (ii) credit or refund the Price for such Nonconforming Goods pursuant to the terms set forth herein. Notwithstanding the foregoing, the only remedy for Nonconforming Goods that are custom systems is repair (not refund or replacement). No returns for Nonconforming Goods are allowed after thirty (30) days from the original shipping date.

(c) Buyer acknowledges and agrees that the remedies set forth in Section 7(a) are Buyer's exclusive remedies for the delivery of Nonconforming Goods. Except as provided under Section 7(a) and Section 14, all sales of Goods to Buyer are made on a one-way basis and Buyer has no right to return Goods purchased under this Agreement to Seller.

8. Price.

(a) Buyer shall purchase the Goods from Seller at the prices (the "**Prices**") set forth in Seller's published catalogue literature in force as of the date of the Sales Quotation. However, the Prices shown in such catalogue literature or any other publication are subject to change without notice. Unless specifically stated to the contrary in the Sales Quotation, quoted Prices and discounts are firm for thirty (30) days from the date of the Sales Quotation. Unless otherwise stated, prices are quoted EXW (Incoterms 2010), Shipping Point. Unless otherwise stated in the Acknowledgement, if the Prices should be increased by Seller before delivery of the Goods to a carrier for shipment to Buyer, then these Terms shall be construed as if the increased prices were originally inserted herein, and Buyer shall be billed by Seller on the basis of such increased prices.

(b) All Prices are exclusive of all sales, use and excise taxes, and any other similar taxes, duties and charges of any kind imposed by any governmental authority on any amounts payable by Buyer. Buyer shall be responsible for all such charges, costs and taxes (present or future); provided, that, Buyer shall not be responsible for any taxes imposed on, or with respect to, Seller's income, revenues, gross receipts, personnel or real or personal property or other assets.

9. Payment Terms.

(a) Unless otherwise provided in the Acknowledgement, if Buyer has approved credit with Seller, Buyer shall pay all invoiced amounts due to Seller within thirty (30) days from the date of Seller's invoice. If Seller does not have Buyer's financial information and has not provided pre-approved credit terms for Buyer, the payment must be made in cash with order or C.O.D. in US dollars. If Buyer has approved credit terms, the payment may be made by cash with order, wire transfer of immediately available funds, or check in US dollars. Certain products require a down payment. Any payment terms other than set forth above will be identified in the Acknowledgement. Notwithstanding anything herein to the contrary, all prepaid deposits and down payments are non-refundable. If a deposit is not received when due, Seller reserves the right to postpone manufacturing of Goods until payment is received. Seller will not be responsible for shipment delays due to deposit payment delays.

(b) In Seller's sole discretion, Seller may access Buyer interest on all late payments at the lesser of the rate of 1.5% per month or the highest rate permissible under applicable law, calculated daily and compounded monthly. Buyer shall reimburse Seller for all costs incurred in collecting any late payments, including, without limitation, attorneys' fees. In addition to all other remedies available under these Terms or at law (which Seller does not waive by the exercise of any rights hereunder), Seller shall be entitled to suspend the delivery of any Goods if Buyer fails to pay any amounts when due hereunder and such failure continues for ten (10) days following written notice thereof.

(c) Buyer shall not withhold payment of any amounts due and payable by reason of any set-off of any claim or dispute with Seller, whether relating to Seller's breach, bankruptcy or otherwise.

10. Intellectual Property; Software License.

(a) To the extent that any Goods provided under this Agreement contains software, whether pre-installed, embedded, in read only memory, or found on any other media or other form ("**Software**"), such Software and accompanying documentation are licensed to Buyer, not sold and shall remain the sole and exclusive property of Seller or third party licensors of Seller. Seller grants Buyer a non-exclusive license to use the Software solely as provided in and in connection with the use of the Goods in which such Software is contained and in accordance with any applicable user documentation provided with such Goods and subject to the provisions of this Agreement. Certain of Seller's Goods may include third party software such as computer operating systems. Licenses to such third party software are subject to the terms and conditions of any applicable third party software license agreements. Unless identified in the Acknowledgement, no license is granted by Seller with respect to such third party software products that may be provided with the Goods (if any). Seller makes no warranties regarding any third party software that may accompany the Goods or otherwise and such software is explicitly included in the definition of Third Party Products below.

(b) Buyer shall not copy, modify, or disassemble, or permit others to copy, modify, or disassemble, the Software, nor may Buyer modify, adapt, translate, reverse assemble, decompile, or otherwise attempt to derive source code from the Software. Buyer shall not transfer possession of the Software except as part of, or with, the Goods, and each such transfer shall be subject to the restrictions contained herein. Buyer may not sublicense, rent, loan, assign or otherwise transfer the Software or documentation, and Buyer shall retain on all copies of the Software and documentation all copyright and other proprietary notices or legends appearing therein or thereon. Seller may terminate this license upon written notice for any violation of any of the terms of this license

or any material breach of any provision of this Agreement. Buyer shall immediately discontinue use of the Software upon any termination of this license or Agreement. This license shall terminate upon any termination of the Agreement.

(c) All patents, trademarks, copyrights or other intellectual property rights embodied in the Goods, including without limitation the Software, are owned by Seller and its licensors. Seller and its licensors retain all right, title and interest in such intellectual property rights. Except as expressly set forth herein, no license rights or ownership in or to any of the foregoing is granted or transferred hereunder, either directly or by implication. ALL RIGHTS RESERVED.

(d) If Buyer is the United States Government or any agency thereof, each of the components of the Software and user documentation are a “commercial item,” and “computer software” as those terms are defined at 48 C.F.R. 2.101, consisting of “commercial computer software” and “commercial computer software documentation,” as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, all United States government Buyers acquire only those rights in the Software and user documentation that are specified in this Agreement.

11. Installation and Other Services. Seller shall provide installation services (“**Installation Services**”) to Buyer if set forth in the Acknowledgment. If Installation Services are provided for in the Acknowledgment, Buyer will prepare the location for the installation consistent with Buyer’s written specifications and Buyer will install necessary system cable and assemble any necessary equipment or hardware not provided by Seller, unless agreed otherwise in writing by the parties. For Goods that will be operated on or in connection with Buyer supplied hardware or software, Buyer is responsible for ensuring that its hardware and software conform with Seller minimum hardware and software requirements as made available to Buyer. Seller shall provide other field services, such as maintenance visits and field repairs (the “**Other Services**” and together with the Installation Services, the “**Services**”) if set forth in the Acknowledgment.

12. Limited Warranty.

(a) Subject to the exceptions and upon the conditions set forth herein, Seller warrants to Buyer that for a period of one (1) year from the date of shipment (“**Warranty Period**”), that such Goods will be free from material defects in material and workmanship.

(b) Notwithstanding the foregoing and anything herein to the contrary, the warranty set forth in this Section 12 shall be superseded and replaced in its entirety with the warranty set forth on **Exhibit A** hereto if the Goods being purchased are specialty products, which include, without limitation, laser products, fiber markers, custom systems, workstations, Seller-installed products, non-catalogue products and other custom-made items (each a “**Specialty Product**”).

(c) **EXCEPT FOR THE WARRANTY SET FORTH IN SECTION 12(A), SELLER MAKES NO WARRANTY WHATSOEVER WITH RESPECT TO THE GOODS (INCLUDING ANY SOFTWARE) OR SERVICES, INCLUDING ANY (a) WARRANTY OF MERCHANTABILITY; (b) WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE; (c) WARRANTY OF TITLE; OR (d) WARRANTY AGAINST INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS OF A THIRD PARTY; WHETHER EXPRESS OR IMPLIED BY LAW, COURSE OF DEALING, COURSE OF PERFORMANCE, USAGE OF TRADE OR OTHERWISE.**

(d) Products manufactured by a third party and third party software (“**Third Party Product**”) may constitute, contain, be contained in, incorporated into, attached to or packaged together with, the Goods. Third Party Products are not covered by the warranty in Section 12(a). For the avoidance of doubt, **SELLER MAKES NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO ANY THIRD PARTY PRODUCT, INCLUDING ANY (a) WARRANTY OF MERCHANTABILITY; (b) WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE; (c) WARRANTY OF TITLE; OR (d) WARRANTY AGAINST INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS OF A THIRD PARTY; WHETHER EXPRESS OR IMPLIED BY LAW, COURSE OF DEALING, COURSE OF PERFORMANCE, USAGE OF TRADE OR OTHERWISE.** Notwithstanding the foregoing, in the event of the failure of any Third Party Product, Seller will assist (within reason) Buyer (at Buyer’s sole expense) in obtaining, from the respective third party, any (if any) adjustment that is available under such third party’s warranty.

(e) Seller shall not be liable for a breach of the warranty set forth in Section 12(a) unless: (i) Buyer gives written notice of the defect, reasonably described, to Seller within five (5) days of the time when Buyer discovers or ought to have discovered the defect and such notice is received by Seller during the Warranty Period; (ii) Seller is given a reasonable opportunity after receiving the notice to examine such Goods; (iii) Buyer (if requested to do so by Seller) returns such Goods (prepaid and insured to Seller at 1820 South Myrtle Avenue, Monrovia, CA 91016 or to such other location as designated in writing by Seller) to Seller pursuant to Seller’s RMA procedures and Buyer obtains a RMA number from Seller prior to returning such Goods for the examination to take place; and (iii) Seller reasonably verifies Buyer’s claim that the Goods are defective and that the defect developed under normal and proper use.

(f) Seller shall not be liable for a breach of the warranty set forth in Section 12(a) if: (i) Buyer makes any further use of such Goods after giving such notice; (ii) the defect arises because Buyer failed to follow Seller’s oral or written instructions as to the storage, installation, commissioning, use or maintenance of the Goods; (iii) Buyer alters or repairs such Goods without the prior written consent of Seller; or (iv) repairs or modifications are made by persons other than Seller’s own service personnel, or an authorized representative’s personnel, unless such repairs are made with the written consent of Seller in accordance with procedures outlined by Seller.

(g) All expendables such as electrodes are warranted only for defect in material and workmanship which are apparent upon receipt by Buyer. The foregoing warranty is negated after the initial use.

(h) Subject to Section 12(e) and Section 12(f) above, with respect to any such Goods during the Warranty Period, Seller shall, in its sole discretion, either: (i) repair or replace such Goods (or the defective part) or (ii) credit or refund the price of such Goods at the pro rata contract rate, provided that, if Seller so requests, Buyer shall, at Buyer’s expense, return such Goods to Seller.

(i) **THE REMEDIES SET FORTH IN SECTION 12(H) SHALL BE BUYER’S SOLE AND EXCLUSIVE REMEDY AND SELLER’S ENTIRE LIABILITY FOR ANY BREACH OF THE LIMITED WARRANTY SET FORTH IN SECTION 12(A).** Representations and warranties made by any person, including representatives of Seller, which are inconsistent or in conflict with the terms of this warranty, as set forth above, shall not be binding upon Seller.

13. Limitation of Liability.

(a) **IN NO EVENT SHALL SELLER BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR PUNITIVE DAMAGES, LOST PROFITS OR REVENUES OR DIMINUTION IN VALUE, LOSS OF INFORMATION OR DATA, OR PERSONAL INJURY OR DEATH ARISING IN ANY WAY OUT OF THE MANUFACTURE, SALE, USE, OR INABILITY TO USE ANY GOODS, SOFTWARE OR SERVICE, OR ARISING OUT OF OR RELATING TO ANY BREACH OF THESE TERMS, WHETHER OR NOT THE POSSIBILITY OF SUCH DAMAGES HAS BEEN DISCLOSED IN ADVANCE BY BUYER OR COULD HAVE BEEN REASONABLY FORESEEN BY BUYER, REGARDLESS OF THE LEGAL OR EQUITABLE THEORY (CONTRACT, TORT OR OTHERWISE) UPON WHICH THE CLAIM IS BASED, AND**

NOTWITHSTANDING THE FAILURE OF ANY AGREED OR OTHER REMEDY OF ITS ESSENTIAL PURPOSE.

(b) IN NO EVENT SHALL SELLER'S AGGREGATE LIABILITY ARISING OUT OF OR RELATED TO THIS AGREEMENT, WHETHER ARISING OUT OF OR RELATED TO BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE) OR OTHERWISE, EXCEED THE TOTAL OF THE AMOUNTS PAID TO SELLER FOR THE GOODS SOLD HEREUNDER.

(c) ALL WARRANTIES SET FORTH HEREIN, DIRECT OR IMPLIED, ARE VOIDED IF THE INITIAL INSTALLATION AND START-UP OF THE SUBJECT GOOD IS NOT SUPERVISED BY AN AUTHORIZED REPRESENTATIVE OF SELLER. AFTER INSTALLATION, ANY RE-ALIGNMENT, RE-CLEANING, OR RE-CALIBRATION, PROVIDED THEY ARE NOT RELATED TO A PROVEN DEFECT IN MATERIALS OR WORKMANSHIP, SHALL BE PERFORMED BY AN AUTHORIZED REPRESENTATIVE OF SELLER AT THE CURRENT SERVICE RATES.

(d) WHERE GOODS ARE SUBJECT TO A MOVE TO ANOTHER LOCATION AFTER THE ORIGINAL INSTALLATION HAS BEEN MADE, THE WARRANTY MAY BE MAINTAINED ONLY IF SUPERVISED BY AN AUTHORIZED REPRESENTATIVE OF SELLER. SELLER, FOR A SERVICE CHARGE, WILL ARRANGE FOR AND SUPERVISE THE DISCONNECTION, TRANSPORTATION, REINSTALLATION AND START-UP OF THE EQUIPMENT. CLAIMS FOR DAMAGE IN SHIPMENT ARE THE RESPONSIBILITY OF BUYER AND SHALL BE FILED PROMPTLY WITH THE TRANSPORTATION COMPANY.

14. Return Goods Policy. Seller's products may be returned to Seller for credit within sixty (60) days of shipment subject to the following conditions.

(a) In order to return products for credit, Buyer must obtain a RMA number from Seller. Upon receipt, it must be executed by an authorized person and then returned with the Goods. Goods returned to Seller without a RMA will be returned at Buyer's expense.

(b) Goods are to be returned to Seller at 1820 South Myrtle Avenue, Monrovia, CA 91016 with Freight Prepaid. Seller will not accept collect shipments.

(c) Restocking fees will be assessed in accordance with the following schedules: (i) Goods returned within the first thirty (30) days from shipment date will be restocked less twenty percent (20%) of the amount billed on the original invoice. (ii) Goods returned over thirty (30) days of shipment but less than sixty (60) days will be restocked less thirty percent (30%) of the amount billed on the original invoice. (iii) No returns are allowed after sixty (60) days from the original shipping date.

(d) The restocking fees set forth above are the minimum fees. If a returned Good requires rework to restore it to a saleable condition, further charges will be assessed. Seller's quality assurance department will document the condition of the Goods when received by Seller and report their findings to Buyer.

(e) Notwithstanding the foregoing provisions of this Section 14, the following Goods cannot be returned, are not eligible for any credit and cannot be restocked: (i) custom or modified products and (ii) any expendable product(s) that have been used.

15. Compliance with Law and Indemnification. Buyer shall comply with all applicable laws, regulations and ordinances. Buyer shall maintain in effect all the licenses, permissions, authorizations, consents and permits that it needs to carry out its obligations under this Agreement. Buyer shall comply with all export and import laws of all countries involved in the sale of the Goods under this Agreement or any resale of the Goods by Buyer. Goods, Services and technical data delivered by Seller shall be subject to U.S. export controls. Buyer shall, and shall cause its customers to, obtain all licenses, permits and approvals required by any government and shall comply with all applicable laws, rules, policies and procedures of the applicable government and other competent authorities. Buyer will indemnify and hold Seller harmless for any violation or alleged violation by Buyer of such laws, rules, policies or procedures. Buyer shall not transmit, export or re-export, directly or indirectly, separately or as part of any system, the Goods or any technical data (including processes and Services) received from Seller, without first obtaining any license required by the applicable government, including without limitation, the U.S. government. Buyer also certifies that none of the Goods or technical data supplied by Seller under this Agreement will be sold or otherwise transferred to, or made available for use by or for, any entity that is engaged in the design, development, production or use of nuclear, biological or chemical weapons or missile technology. No Buyer information will be deemed "technical data" unless Buyer specifically identifies it to Seller as such. Buyer assumes all responsibility for shipments of Goods requiring any government import clearance. Seller may terminate this Agreement if any governmental authority imposes antidumping or countervailing duties or any other penalties on Goods. For all international shipments, Seller requires that all required Export Control documentations, including Form BIS-711 Statement by Ultimate Consignee and Purchases, are submitted by Buyer along with the purchase order. Seller reserves the right to postpone shipment until all documentations are completed and submitted to Seller. Seller will not be responsible for shipment delays due to non-compliance by Buyer of the foregoing two sentences.

16. Termination. In addition to any remedies that may be provided under these Terms, Seller may terminate this Agreement with immediate effect upon written notice to Buyer, if Buyer: (i) fails to pay any amount when due under this Agreement and such failure continues for ten (10) days after Buyer's receipt of written notice of nonpayment; (ii) has not otherwise performed or complied with any of these Terms, in whole or in part; or (iii) becomes insolvent, files a petition for bankruptcy or commences or has commenced against it proceedings relating to bankruptcy, receivership, reorganization or assignment for the benefit of creditors.

17. Waiver. No waiver by Seller of any of the provisions of this Agreement is effective unless explicitly set forth in writing and signed by Seller. No failure to exercise, or delay in exercising, any rights, remedy, power or privilege arising from this Agreement operates or may be construed as a waiver thereof. No single or partial exercise of any right, remedy, power or privilege hereunder precludes any other or further exercise thereof or the exercise of any other right, remedy, power or privilege.

18. Confidential Information. All non-public, confidential or proprietary information of Seller, including, but not limited to, specifications, samples, patterns, designs, plans, drawings, documents, data, business operations, customer lists, pricing, discounts or rebates, disclosed by Seller to Buyer, whether disclosed orally or disclosed or accessed in written, electronic or other form or media, and whether or not marked, designated or otherwise identified as "confidential," in connection with this Agreement is confidential, solely for the use of performing this Agreement and may not be disclosed or copied unless authorized in advance by Seller in writing. Upon Seller's request, Buyer shall promptly return all documents and other materials received from Seller. Seller shall be entitled to injunctive relief for any violation of this Section 18. This Section 18 does not apply to information that is: (a) in the public domain through no fault of Buyer; (b) known to Buyer at the time of disclosure without restriction as evidenced by its records; or (c) rightfully obtained by Buyer on a non-confidential basis from a third party.

TL-080B METRIC THIN-LINE™ WELD HEADS

19. Force Majeure. Seller shall not be liable or responsible to Buyer, nor be deemed to have defaulted or breached this Agreement, for any failure or delay in fulfilling or performing any term of this Agreement when and to the extent such failure or delay is caused by or results from acts or circumstances beyond the reasonable control of Seller including, without limitation, acts of God, flood, fire, earthquake, explosion, governmental actions, war, invasion or hostilities (whether war is declared or not), terrorist threats or acts, riot, or other civil unrest, national emergency, revolution, insurrection, epidemic, lock-outs, strikes or other labor disputes (whether or not relating to either party's workforce), or restraints or delays affecting carriers or inability or delay in obtaining supplies of adequate or suitable materials, materials or telecommunication breakdown or power outage (each a "**Force Majeure Event**"), provided that, if the event in question continues for a continuous period in excess of thirty (30) days, Buyer shall be entitled to give notice in writing to Seller to terminate this Agreement.

20. Assignment. Buyer shall not assign any of its rights or delegate any of its obligations under this Agreement without the prior written consent of Seller. Any purported assignment or delegation in violation of this Section 20 is null and void. No assignment or delegation relieves Buyer of any of its obligations under this Agreement.

21. Relationship of the Parties. The relationship between the parties is that of independent contractors. Nothing contained in this Agreement shall be construed as creating any agency, partnership, joint venture or other form of joint enterprise, employment or fiduciary relationship between the parties, and neither party shall have authority to contract for or bind the other party in any manner whatsoever.

22. No Third-Party Beneficiaries. This Agreement is for the sole benefit of the parties hereto and their respective successors and permitted assigns and nothing herein, express or implied, is intended to or shall confer upon any other person or entity any legal or equitable right, benefit or remedy of any nature whatsoever under or by reason of these Terms.

23. Governing Law. All matters arising out of or relating to this Agreement is governed by and construed in accordance with the internal laws of the State of California without giving effect to any choice or conflict of law provision or rule (whether of the State of California or any other jurisdiction) that would cause the application of the laws of any jurisdiction other than those of the State of California.

24. Dispute Resolution.

(a) If Buyer is an entity formed under the laws of the United States of America, or any of its states, districts or territories ("**U.S. Law**"), then any dispute, legal suit, action or proceeding arising out of or relating to this Agreement shall be adjudicated and decided in the federal courts of the United States of America or the courts of the State of California in each case located in the City of Los Angeles and County of Los Angeles, California and each party irrevocably submits to the exclusive and personal jurisdiction of such courts in any such dispute, suit, action or proceeding.

(b) If Buyer is an entity formed under the laws of any country, state, district or territory other than U.S. Law, then the parties irrevocably agree that any dispute, legal suit, action or proceeding arising out of or relating to this Agreement shall be submitted to the International Court of Arbitration of the International Chamber of Commerce ("**ICC**") and shall be finally settled under the Rules of Arbitration of the ICC. The place and location of the arbitration shall be in Los Angeles, California, pursuant to the ICC's Rules of Arbitration and shall be finally settled in accordance with said rules. The arbitration shall be conducted before a panel of three arbitrators. Each party shall select one arbitrator and the two arbitrators so selected shall select the third arbitrator, who shall act as presiding arbitrator. Notwithstanding the foregoing, if the matter under dispute is \$500,000 or less, there shall only be one arbitrator who shall be mutually selected by both parties. If the party-selected arbitrators are unable to agree upon the third arbitrator, if either party fails to select an arbitrator, or in the case that only one arbitrator is required and the parties are unable to agree, then the International Court of Arbitration shall choose the arbitrator. The language to be used in the arbitral proceeding shall be English. The arbitrator(s) shall have no authority to issue an award that is contrary to the express terms of this Agreement or the laws of the State of California or applicable US Federal Law, and the award may be vacated or corrected on appeal to a court of competent jurisdiction for any such error. The arbitrator(s) shall be specifically empowered to allocate between the parties the costs of arbitration, as well as reasonable attorneys' fees and costs, in such equitable manner as the arbitrator(s) may determine. The arbitrator(s) shall have the authority to determine issues of arbitrability and to award compensatory damages, but they shall not have authority to award punitive or exemplary damages. Judgment upon the award so rendered may be entered in any court having jurisdiction or application may be made to such court for judicial acceptance of any award and an order of enforcement, as the case may be. In no event shall a demand for arbitration be made after the date when institution of a legal or equitable proceeding based upon such claim, dispute or other matter in question would be barred by the applicable statute of limitations. Notwithstanding the foregoing, either party shall have the right, without waiving any right or remedy available to such party under this Agreement or otherwise, to seek and obtain from any court of competent jurisdiction any interim or provisional relief that is necessary or desirable to protect the rights or property of such party, pending the selection of the arbitrator(s) hereunder or pending the arbitrator(s)' determination of any dispute, controversy or claim hereunder.

25. Notices. All notices, request, consents, claims, demands, waivers and other communications hereunder (each, a "**Notice**") shall be in writing and addressed to the parties at the addresses set forth on the face of the Acknowledgement or to such other address that may be designated by the receiving party in writing. All Notices shall be delivered by personal delivery, nationally recognized overnight courier (with all fees pre-paid), facsimile (with confirmation of transmission) or certified or registered mail (in each case, return receipt requested, postage prepaid). Except as otherwise provided in this Agreement, a Notice is effective only (a) upon receipt of the receiving party, upon confirmation of delivery by nationally recognized overnight courier or upon forty-eight (48) hours after being sent by certified or registered mail (as applicable), and (b) if the party giving the Notice has complied with the requirements of this Section 25.

26. Severability. If any term or provision of this Agreement is invalid, illegal or unenforceable in any jurisdiction, such invalidity, illegality or unenforceability shall not affect any other term or provision of this Agreement or invalidate or render unenforceable such term or provision in any other jurisdiction.

27. Survival. Provisions of these Terms which by their nature should apply beyond their terms will remain in force after any termination or expiration of this Order including, but not limited to, the following provisions: Compliance with Laws, Confidentiality, Governing Law, Dispute Resolution, Survival, and the restrictions on Software in Sections 10(b), (c) and (d).

CHAPTER 1: SYSTEM DESCRIPTION

Section I. Features

Overview

This manual is organized to assist you in getting productive quickly with your TL-080B Metric Thin-Line Weld Head, hereinafter referred to as the **Weld Head**. *Chapter 1* describes the equipment, *Chapter 2* describes installation, *Chapter 3* describes operating procedures so you can run the weld head safely and efficiently, and *Chapter 4* describes maintenance and troubleshooting procedures.

The Weld Heads come in different sizes and configurations and may be installed on Amada Weld Tech mounting hardware, custom mounting posts, or installed directly on your equipment using the two tapped holes on the rear of the weld head. Some heads are manually-actuated, others are air-actuated. Mounting templates and all necessary installation hardware are shipped with each weld head.

These Weld Heads are precision, low inertia, force fired Weld Heads with a narrow vertical profile. Their 4.5 cm (1.75 inch) width, 2.5cm (1 inch) stroke, 89 - 178 N (20 - 40 pound) maximum force range, and throat depth allow their use in a wide variety of precision resistance welding applications. Both in-line and offset electrode holders are available. The dimensions of the mounting post and the main shaft have been selected to ensure that the electrodes do not "wipe" more than 0.076 mm (0.003 inch) on the 89 N (20 pound) heads and 0.102mm (0.004 inch) on the 178 N (40 pound) heads. This is an important consideration in critical welding applications such as hermetic seals and pressure transducers.

The Weld Head is a "production line" head with a bearing life designed for a minimum of 20 million operations. Amada Weld Tech Weld Heads excel at precisely placing consistent, high quality welds. Their low inertia, lightweight design assures fast dynamic response, allowing the electrodes to follow the minute expansion and contraction of the weld joint as it heats and cools during the welding cycle. A differential motion Force-Firing System initiates the power source at the precise moment the Preset Firing Force is applied to the workpieces. Linear ball bearing bushings and an oversized, anti-rotational bearing system provide true, vertical in-line electrode motion, assuring smooth vertical travel of the upper electrode arm. This system minimizes the wiping action of the electrodes, even at maximum force settings.

Preset Firing Force

Firing force is continuously adjustable from 0.22 kg (8 ounces), 11kg (4 ounces), 89 N (20 pound), or 178 N (40 pound) depending on the model. An adjustable Tare Spring on 89 N (20 pound) models compensates for the weight of the electrode holders. The Firing Force Adjustment Cam easily adjusts the sensitivity of the Firing Force Switch.

Up And Down Stops

The Weld Heads have adjustable Upstops and Downstops. The Downstop can be used to limit excessive downward travel. The Upstop controls the stroke, and consequently, the travel time of the head. In automated machine applications, using a stroke of less than 3.2 mm (1/8 inch) may significantly reduce bearing life. On air-actuated models, the *EZ-AIR* head prevents overforce.

Electrodes

The Weld Heads accept a wide variety of standard and special purpose electrodes. There are models available, which accept 3mm or 6mm diameter electrodes, 6mm diameter eccentric electrodes, Unibond⁷, and Unitip⁷ Electrodes. The optional Model ETB4 Table Electrode fits Models TL-080B (and legacy models; 84M, and 86M).

Insulation

The Terminal Block, Flexible Copper Strap, and Upper Electrode Assembly are electrically insulated from the frame of the Weld Head. The Frame, Support Post, and Support Base are grounded to the bench top.

Welding Cables

Depending upon model, either # 2 or # 2/0 Welding Cables are provided to connect the Weld Heads to the power source. Amada Weld Tech Weld Heads deliver maximum performance when used with the appropriate Amada Weld Tech Power Supplies.

Footpedal Actuation


The Weld Heads, model number suffix "F," are footpedal (manually) actuated. Amada Weld Tech offers two different footpedal styles:

- 1 The Model CP Cable Pedal is a treadle-type cable actuator providing an approximate 3 to 1 mechanical advantage. This pedal is used with Models TL-080B-F/M (and legacy Model 86MF).
- 2 The Model MSP, Swing Action Footpedal, provides an approximate 5 to 1 mechanical advantage and is used with the Model TL-088B-F/M (and legacy model 84MF).

Air Actuation

The air-actuated weld heads are supplied with factory-installed *EZ-AIR*, an Amada Weld Tech pneumatic control that actuates the electrodes and maintains a preset firing force. At a predetermined firing force, *EZ-AIR* closes the inlet and outlet valves to the weld head actuation cylinder and eliminates over-force. The air-actuated heads are easy to incorporate into automated welding systems. *EZ-AIR* can be energized by most of the Amada Weld Tech Power Supplies, or by a Model FSAC Footswitch. The Footswitch can be a single or two-level type, dependent upon the power supply and the user's preference. For *EZ-AIR* instructions, see the separate *EZ-AIR* Operator Manual supplied with the weld head.

Section II. System Components



Typical TL-080B Metric Weld Head

Model TL-080B-F/M (and legacy model 80MA-EZ)

These are conventional, 89 N (20 pound) capacity welding heads with offset, opposed electrodes. Both the pedestal mounting (post) and lower electrode assembly can be removed and replaced by custom fixtures. All air-actuated heads include *EZ-AIR*. Models TL-080B-F/M (and legacy model 80MA-EZ) are supplied with one pair of 3mm diameter Glidcop7 Straight electrodes. Glidcop is a registered trademark of Glidden Metals Company.

Legacy Model 84MF and 84MA-EZ

This is a 178 N (40 pound) welding head with offset, opposed electrodes. The lower electrode assembly can be removed and replaced by a table electrode or a custom fixture. Legacy Models 84MF and 84MA-EZ are supplied with one pair of ER6M50, 6mm diameter Glidcop Straight electrodes.

Legacy Model 86MF and 86MA-EZ

This model features a Parallel Gap Weld Head which is used for fine wire or ribbon bonding and parallel gap reflow soldering applications. It features an easily read, high-resolution, digital force indicator that permits accurate resetting of force values. The Legacy Model 86MF includes a voltage sensing and thermocouple adapter cable.

Compliant electrode holders allow the electrodes to conform to uneven workpiece surfaces. The legacy Model 86MF is supplied with Model EU1000, RWMA 2 Unibond Electrodes. Unitip Electrodes should **not** be used with the air actuated legacy 86MA-EZ Weld Head, since any misadjustment of the Down Speed Flow Control would probably damage the delicate tip of the electrode.

Model TL-088B-F/M and TL-088B-MA-EZ

This is designed to function as either a series or a parallel weld head. The Model TL-088B's Electrode Holders are designed to hold eccentric electrodes which can be rotated, parallel to their length and adjusted with the electrode holders, so that the separation between the electrode faces is from 0.0 - 8.4 mm (0.00 - 0.330 inches). The welding force on each electrode can be independently set between 2.2 - 89 N (0.5 - 20 pounds). Model TL-088B-MA-EZ includes *EZ-AIR*. Model TL-088B Weld Heads are supplied with one pair of ES0850E, Glidcop Eccentric Electrodes.


Section III. Welding Capabilities

Series Welding

In series welding applications, both electrodes contact the *same* surface of each workpiece. The weld current flows from one electrode through the workpiece to the other electrode. This technique is used to weld workpieces which have only one surface accessible.

The work surface, or a user supplied fixture, acts as a support for the workpieces in series welding. If the Table is insulated from the workpieces, there is no possibility of shunting current away from the (-) electrode.

To use Model TL-088B Weld Heads in the series welding mode, you *must* use the **Model DFS/88** Series Firing Switch Junction Box, which is supplied with the head.




Step welding

In step welding, the size of the weld and the surface marking is frequently controlled by the diameter of the face of each electrode. If the (+) Electrode is significantly larger than the (-) Electrode the lower workpiece will not have any marking and the weld will be under the (-) Electrode.

The Table Electrode, or a user supplied fixture, acts as a support for the workpieces in step welding.

If the Table is insulated from the workpieces, there is no possibility of shunting current away from the (-) electrode.



Section IV. Operating Controls

TL-080B Metric Air Actuation Specifications

PARAMETER / MODEL	TL-088B-MA-EZ (and Legacy Models 80MA & 86MA)	Legacy Model 84MA
Input Air Pressure - Nominal / Maximum	448 / 690 kPa (65 / 100 psi)	65 / 100 psi (448 / 690 kPa)
Regulator Output - Maximum	448 kPa (65 psi)	448 kPa (65 psi)
Cycle Rate (full strokes/sec) at Min. Force at greater than 20% of Rated Force	1.0 2.5	1.0 2.5
Solenoid Valve Voltage (AC volts)	24V Standard	24V Standard
Air Cylinder Inside Diameter	0.75 inch (1.9 cm)	1.0625 inch (2.7 cm)

Air Cylinders

The Model TL-088B-MA-EZ uses **two** air cylinders and **two** *EZ-AIR* pneumatic controls, all other legacy air-actuated models are supplied with **one** air cylinder and **one** *EZ-AIR*.

Footswitches

A one-level Footswitch actuates the head, and the Firing Switch in the head initiates the welding sequence. The first level of a two-level Footswitch actuates the head. The second level and the Force Firing Switch initiate the welding sequence. A two-level Footswitch is recommended when the operator is required to position the workpieces. It also allows the operator to actuate an air head without initiating the weld cycle since both the Firing Switch **and** the second level of the Footswitch must close before the weld portion of the sequence can begin.

CHAPTER 2

INSTALLATION

Section I. Introduction

Overview

Before you start installation, become familiar with the specific model you are using. As shown below, the Weld heads come in different sizes and configurations which require different mounting baseplates, mounting posts, and installation hardware.

Installation procedures depend on the size and configuration of a specific model, and whether the weld head, mounting post, and baseplate were shipped as separate pieces requiring assembly or shipped from the factory fully assembled. Some manually-actuated heads are shipped with foot pedals attached, others are not. Air-actuated models are shipped with factory-installed *EZ-AIR* pneumatic controls.

Despite differences from model-to-model, the installation principle is the **same** for each head:

- If not already attached, the weld head mounting post is attached to the baseplate
- The weld head mounting baseplate is bolted securely to a workbench
- The weld head is attached to the mounting post
- If necessary, the air head (if used), foot pedal (if used), and optics (if used) are installed
- Electrodes and weld cables are installed on the weld head


Mounting Posts

The Weld Heads may be purchased with or without mounting hardware. Amada Weld Tech provides three types of mounting posts (and corresponding installation hardware) designed for different models:

Mounting Tube

Smaller Weld Heads are installed on short mounting tubes. These are factory-installed and do not require any assembly by the user.

Mounting tubes come in fixed lengths, the height of the weld head is not adjustable.



Dual-Post

This consists of two parallel posts connected at the top and bottom, leaving an open slot for the full length of the post. The mounting screws are installed from the back of the post and screwed directly into the weld head. The mounting screws can be loosened from the back of the post for adjusting the height of the weld head.

Channeled Post

This is an extruded aluminum post with channels on the front and back. By inserting T-Nuts into the channels, mounting plates can be screwed onto the front (for weld head), back (for air head), or both sides of the post (only the weld head is shown). This installation allows you to adjust the height of the weld head and air head separately.

Section II. Weld Head Installation

Overview

First, this section will give "Typical Installation" instructions that are common to *all* TL-080B Metric Weld Heads. Then, additional instructions for installing *specific* weld head models are listed by model number.


Before you start installation:

- Make sure you are familiar with the mounting configurations and installation hardware described and illustrated in this section.
- Read the *Typical Installation* instructions **and** the instructions for the *specific* weld head you want to install.
- Make sure you have all necessary parts and mounting hardware. Use the shipping list as a reference. Verify that the paper mounting template corresponds to the model number of the weld head. If you do **not** have the correct template, contact Amada Weld Tech at the address shown in the front of the manual.

Typical Installation


NOTE: Allow sufficient working space, usually 20.32 - 25.4cm (8 - 10 inches), between the front edge of the bench and the mounting base. This allows the operator to use the bench as a support when positioning the workpiece.

- 1 Place the mounting template in the desired location on the workbench and tape it in place.
- 2 Drill the mounting holes as shown on the template.




CHAPTER 2: INSTALLATION

- 3 If necessary, install the weld head mounting post to the baseplate.




- 4 If you are using optics (microscope and/or illuminator), screw the optics mounting post to the optics baseplate (if not already installed).

NOTE: Follow the assembly instructions provided with the Optics. If necessary, drill holes in the Optics baseplate in order to accommodate the screws used to mount the weld head.




- 5 If not already attached, install the weld head mounting post to the weld head baseplate.



- 6 Screw the weld head mounting baseplate (and optics baseplate if used) to the workbench.

NOTE: If you are using optional optics (microscope/illuminator), install the optics baseplate between the workbench and the weld head mounting baseplate.


- 7-A Install the weld head on the **Dual-Post**.



- A) Install the mounting screws and washers onto the mounting backplate.
- B) Place the weld head on the front of the mounting post, then insert the mounting screws through the slot in the back of the mounting post and screw them into the weld head.
- C) Adjust the weld head to the desired height, then tighten the mounting screws.

CHAPTER 2: INSTALLATION



7-B Install the weld head on the **Channeled-Post**.



- Install the weld head mounting plate onto the weld head using the screws as shown.
- Install the screws, washers, and T-nuts into the weld head mounting plate as shown.
- If necessary, remove the end cap from the mounting post to expose the channels in the mounting post.
- Raise the weld head and mounting plate above the mounting post, insert the bottom T-nut into the front channel of the mounting post, and slowly lower the weld head until you can insert the top T-nut into the channel. Slide the weld head to the desired height, then tighten the mounting screws.
- If you are using an air head, install it on the rear of the mounting post following the procedures in Steps A through D.


Model TL-080B-F/M (and legacy model 86MF) CP Footpedal Installation

- 1 Push down on top of weld head to extend end of pullrod.
- 2 Secure Electrode Holders with string to hold in place.
- 3 Position head (and optional baseplate) on bench as shown.
- 4 Route footpedal cable up through bench (and baseplate).




- 5 Attach cable from footpedal to pullrod (larger hole up) using small screw, which is supplied.
- 6 Untie string and release the electrode holders.
- 7 Depress pedal, and push cable sheath into pullrod hole until it is flush with base.
- 8 Secure sheath with set-screw as illustrated.

CHAPTER 2: INSTALLATION




- 9 Adjust footpedal so that the electrode holders move the distance required by the application.
- 10 Adjust the angle of the treadle so that it provides the electrode stroke necessary for the application and is comfortable for the operator.

Model TL-088B-F/M (and legacy model 84MF) MSP Footpedal Installation



- 1 Screw the head to the bench and Model MSP Footpedal using four (4) screws, washers and nuts supplied with the shipping kit.

- 2 To adjust the height of the head, loosen two hex head cap screws on the mounting plate adapter, as illustrated, and slide Head up or down the mounting stand.
- 3 Pull out the pin on footpedal adapter block, as illustrated. Insert the pullrod and allow the pin to snap back into place.
- 4 Attach the pullrod to footpedal.
- 5 Adjust the height of head, loosen two Allen head cap screws on the mounting plate adapter as shown, and slide Head up or down the mounting stand.
- 6 Attach the pullrod to footpedal. Adjust the angle and length of the footpedal so that it is comfortable for the operator.



Models TL-088B-MA-EZ (and legacy models 80MA-EZ, 84MA-EZ and 86MA-EZ) Air Connection

To connect an air supply to the *EZ-AIR* input, follow the instructions in the separate *EZ-Air* manual.

NOTES:

- You must use a *properly filtered air supply* (690 kPa [100 psi] maximum). Use the *shortest* air lines possible to obtain the fastest mechanical response.
- Install the system in accordance with established safety practices and standards. Anti-Tiedown Palm Buttons are not usually required if the electrode spacing will not allow the operator's fingers to fit between them.



EZ-AIR Air Input

Optics

If you are using any of the optional optics (microscope or illuminator):


- 1 Verify that the optics mounting post is securely attached to the optics baseplate.
- 2 Install the optics following the instructions provided with the optics.

Section III. Connect Weld Cables


Weld Cables and Energy Losses

All Amada Weld Tech weld heads are supplied with the correct weld cables to provide maximum weld energy. If you need to install longer cables, or replace damaged cables,

- **Use #2 AWG for lengths under 30.5 cm (12 inches) and # 2/0 AWG for longer lengths.** Tie or tape cables together to minimize inductive losses. A separation of weld cables surrounding an area of one square foot could result in losses of up to 65%.
- **Use the shortest possible Welding Cables.** It is common to have losses of up to 50% per foot for # 6 cables and 20% for # 2 cables.
- **Both cables must always be on the same side of the head.** Route cables so that they do *not* surround magnetic materials such as air solenoids, tooling, or steel weld heads. The cable routing and weld head design should be such that the secondary loop does not encompass magnetic materials (steel) and/or is not encompassed by any magnetic material.



Connect Cables to Head



CHAPTER 2: INSTALLATION

1 **Model TL-080B (and legacy model 84M):**

Connect one of the two cables supplied to the Power Bar.

Model TL-088B (and legacy model 86M):

Connect one cable to each Power Bar.

- 2 Place the washer, which is supplied, between the head of the Socket Head Screw and the Terminal on the Cable. ***Do NOT place the washer between the Cable and the Power Bar.*** Tighten connections securely; they must be free from oxidation, dirt, and/or grease.
- 3 Connect the other end of the cables to the power supply or output transformer, in accordance with the instructions in its Users' Manual.

Section IV. Install Electrodes and Thermodes




CAUTION

Do **not** modify the electrode holders or attach additional mechanisms to the moving parts of the head. Doing so may hurt welding performance, damage the head, and *void the warranty*.

Model TL-080B (and legacy model 84M)

- 1 Loosen screws and insert electrodes. Loosely tighten screws to hold electrodes in position.
- 2 Align the electrodes, then tighten into position.


NOTE: The maximum distance between the electrode tips is 25.4mm (1.0 inch).



Model TL-088B

- 1 Insert electrodes into electrode holders.
- 2 Lower the electrodes onto a flat workpiece.
- 3 Align the electrodes so that they are parallel as well as perpendicular to the workpiece. Align the electrode tips.
- 4 Rotate the electrodes to obtain the desired distance between the tips (gap). Tighten the screws on the electrode holders.

NOTE: The maximum distance between the electrode tips and the workpiece is 25.4mm (1.0 inch).




CHAPTER 2: INSTALLATION


Legacy Model 86M -- Unibond Electrodes

- 1 Check the voltage sensor cable located on the underside of the electrode arms. Verify that the two slotted head screws which attach the sensing cable to the flexure assemblies are securely tightened.

CAUTION: *Erratic operation results if these cables are loose.*



- 2 Loosen the electrode holder clamp screws. Set the electrode gap adjustment knob for maximum gap width and insert the Unibond electrodes into the holders as illustrated.
- 3 Loosely hold the electrodes in place and rotate the gap adjustment knob to its fully-clockwise (closed) position.
- 4 Orient the electrodes so they contact each other along their entire length and are perpendicular to the surface of the workbench.



NOTE: Position the electrodes vertically in the holder so the electrode tips are aligned.

- 5 Tighten the electrode holder clamp screws.


CAUTION: Do not over-torque the clamp screws. Doing so will deform the flexure, dramatically reducing its life.

- 6 Open the electrodes to the desired operating gap by turning the gap adjustment knob counterclockwise. The maximum distance between the tip of the electrode and the workpiece is 25.4mm (1.0 inch).


Legacy Model 86M -- Unitip Electrodes

- 1 Look at the electrode holders from the top and verify that the holders are aligned from front-to-rear.

CAUTION: Unitip electrodes will be destroyed if the electrode holders are misaligned. The displacement will cause the Unitip to be sheared when the electrode holder clamp screws are tightened.



- 2 Assemble Unitip inside the Model UTA, Unitip Adapter, as shown. The vertical line (insulation) must be centered between the edges of the Unitip Adapter. Insert the assembled electrode into the electrode holder.
- 3 Rotate the gap adjustment knob clockwise until the assembled electrode is lightly held in place. The Unitip and Unitip Adapter should be flush with the top surface of the electrode holder.



NOTE: Unitip electrodes have a fixed gap which can *not* be adjusted. If necessary, rotate the Unitip so that the vertical line on the tip formed by the insulation layer is exactly between the two adapter halves as illustrated. Tighten the two screws on the electrode holder.

CAUTION: *Unitips can be severely damaged by applying excessive bonding forces.* The table on the right lists the maximum operational force limits in both kilograms force (kgf) and ounces (oz). See *Chapter 4* for Unitip cleaning and dressing instructions.

Use of Unibond Electrodes and Unitips should be limited to footpedal actuated weld heads. Their use in air-actuated heads requires great caution in adjusting electrode forces.

The maximum distance between the tip of the electrode and the workpiece is 25.4mm (1.0 inch).

MAXIMUM UNITIP FORCE		
Unitip Model	Max. Force (Kgf)	Max. Force (Oz)
UTM111L	0.94	33
UTM112L	0.94	33
UTM152L	0.47	17
UTM222L	3.75	132
UTM111C	0.94	33
UTM112C	0.94	33
TM222C	3.75	132
UTM224C	3.75	132
UTM237C	4.57	161

Section V. Install Optional Equipment

Model TL-088B-F/M -- Install DFS/88 Series Firing Switch Junction Box

If the TL-088B-F/M is to be used as a *SERIES* type welding head, then connect both Firing Switch Cables to the DFS/88, which is supplied with the head. The DFS/88 connects the Force Firing Switches, which are located inside the heads, in *series*. This means that the power source will *not* be triggered until *both* sides of the head exert the preset firing force on the workpiece.

Use the DFS when the Model TL-088B-F/M are used as parallel type welding heads.

Connect Optional Hall Effect Limit Switch



The Hall Effect Limit Switch cylinder's magnetic disk surrounds the actuation rod located on the top of its internal piston.

The magnetic field which is produced when the piston passes the sensor produces an output which can be used to control other equipment.

- 1 Mount the Hall Effect Switch using the clamp which is supplied.
- 2 Position the switch at the top (bottom) of the cylinder to detect when the head is in the *up* (*down*) position.

- 3 Wire the Hall Effect switch as illustrated:

NOTE: Be sure to include a resistor in series with the output which limits the output current to a *maximum of 50ma*.



CHAPTER 3

OPERATING INSTRUCTIONS

Section I. Getting Started

Installation Checklists

INSTALLATION CHECKLIST FOR ALL HEADS	
✓	Check that the cables are correctly attached at both ends.
✓	Verify that the Firing Switch Cable is attached to the welding power supply (control).
✓	Set the WELD/NO WELD Switch, located on the front of the welding power supply (control), to the NO WELD position.
✓	Verify that the welding power supply (control) is connected to the appropriate power source and that the power is switched to ON.
✓	Switch the welding power supply (control) to ON. Follow the procedures in the manual to program and operate the welding power supply (control).
INSTALLATION CHECKLIST FOR AIR ACTUATED HEADS	
✓	Verify that the air lines are properly connected to the head and the main air supply (65 psi/448 kPa nominal) is turned ON.
✓	Verify that the line cord from the air solenoid is connected to the power supply (control) if required.
✓	Verify that the footswitch is connected to the welding power supply (control).

CHAPTER 3: OPERATING INSTRUCTIONS

Welding Force Theory

Welding force (pressure) is a key variable in the resistance welding process. Excessive or insufficient welding force or pressure can cause a weak weld. More technical information is available from Amada Weld Tech in these publications:

- The Basics of Resistance Welding
- Quality Resistance Welding Solutions, Defining The Optimum Process
- Electrode/Material Selection Guide
- Resistance Welding Spot Welding Applications
- Resistance Welding Troubleshooting Guide
- Technical Service Bulletins on a variety of subjects

Troubleshooting

WELDHEAD TROUBLESHOOTING GUIDE			
SYMPTOM OR PROBLEM	PRIMARY CAUSE Weldhead-Related Cause	PRIORITY*	SOLUTION
Overheating of Weldment	Excess Welding Time	1	Decrease Welding Time (A.C. Welding)
	Insufficient Force	2	Increase force in steps of 10-20%
	Wrong Electrode Material	2	Check Electrode/Material Selection Guide
	Dirty Electrodes	3	Clean electrodes and/or parts to be welded
	Electrode Tip Shape	3	Use constant area electrodes or shape to suit application
Discoloration	Excess Welding Time	1	Decrease Welding Time (A.C. Welding)
	Wrong Electrode Material	1	Check Electrode/Material Selection Guide
	Insufficient Force	2	Increase force in steps of 10-20%
Weak Weld	Insufficient Current/Energy	1	Increase current/energy in steps of 5-10%
	Dirty Electrodes	1	Clean electrodes and/or parts to be welded
	Electrode Tip Shape	1	Use constant area electrodes or shape to suit application
	Mushroomed Electrodes	1	Replace or reshape electrodes or increase cleaning schedule
	Excess Force	2	Decrease force in steps of 10-20%
	Insufficient Force	2	Increase force in steps of 10-20%
	Wrong Electrode Material	2	Check Electrode/Material Selection Guide
	Poor Weldhead Follow-up	3	Reduce mass of top electrode holder assembly

WELDHEAD TROUBLESHOOTING GUIDE			
SYMPTOM OR PROBLEM	PRIMARY CAUSE Weldhead-Related Cause	PRIORITY*	SOLUTION
Insufficient Nugget **	Insufficient Current/Energy	1	Increase current/energy in steps of 5-10%
	Wrong Electrode Material	1	Check Electrode/Material Selection Guide
	Electrode Tip Shape	1	Use constant area electrodes or shape to suit application
	Mushroomed Electrodes	1	Replace or reshape electrodes or increase cleaning schedule
	Dirty Electrodes	2	Clean electrodes and/or parts to be welded
	Excess Force	2	Decrease force in steps of 10-20%
	Insufficient Force	3	Increase force in steps of 10-20%
Metal Expulsion	Excess Current/Energy	1	Decrease current/energy in steps of 5-10%
	Insufficient Force	1	Increase force in steps of 10-20%
	Poor Weldhead Follow-up	1	Reduce mass of top electrode holder assembly***
	Dirty Electrodes	2	Clean electrodes and/or parts to be welded
	Electrode Tip Shape	2	Use constant area electrodes or shape to suit application
Sparking	Excess Current/Energy	1	Decrease current/energy in steps of 5-10%
	Insufficient Force	1	Increase force in steps of 10-20%
	Poor Weldhead Follow-up	1	Reduce mass of top electrode holder assembly***
	Electrode Tip Shape	1	Use constant area electrodes or shape to suit application
	Wrong Electrode Material	2	Check Electrode/Material Selection Guide
	Dirty Electrodes	2	Clean electrodes and/or parts to be welded
Warping	Excess Welding Time	1	Decrease Welding Time (A.C. Welding)
	Excess Force	1	Decrease force in steps of 10-20%
	Electrode Tip Shape	2	Use constant area electrodes or shape to suit application
Electrode Sticking	Insufficient Force	1	Increase force in steps of 10-20%
	Wrong Electrode Material	1	Check Electrode/Material Selection Guide
	Electrode Tip Shape	1	Use constant area electrodes or shape to suit application
	Dirty Electrodes	2	Clean electrodes and/or parts to be welded
	Poor Weldhead Follow-up	3	Reduce mass of top electrode holder assembly ***

CHAPTER 3: OPERATING INSTRUCTIONS

WELDHEAD TROUBLESHOOTING GUIDE			
SYMPTOM OR PROBLEM	PRIMARY CAUSE Weldhead-Related Cause	PRIORITY*	SOLUTION
Electrode Damage	Excess Current/Energy	1	Decrease current/energy in steps of 5-10%
	Insufficient Force	1	Increase force in steps of 10-20%
	Electrode Tip Shape	1	Use constant area electrodes or shape to suit application
	Excess Force	2	Decrease force in steps of 10-20%
	Wrong Electrode Material	2	Check Electrode/Material Selection Guide
	Dirty Electrodes	2	Clean electrodes and/or parts to be welded

* Priority numbers refer to troubleshooting priority, with 1 as highest priority. Start troubleshooting with 1 and then proceed to 2 and so on. When there are multiple causes with the same priority, use personal judgement in determining which is more probable in the specific application.

** In most cases capacitor discharge welds do not have a significant nugget.

*** For non-Amada Weld Tech weld heads.

A certain amount of experimentation is necessary to achieve the proper welding force setting for a specific application. The following are some general rules to make quality welds:

- Larger parts require higher force.
- Larger diameter electrode faces require higher force.
- Higher electrode forces require higher weld currents (energy).

Reflow Soldering Force

The reflow soldering process is not as sensitive to force as resistance welding. Sufficient force or pressure is necessary to ensure adequate thermal conduction and to hold the workpieces as the solder solidifies.

Section II. Model TL-088B-MA-EZ Air-Actuated Head Setup

This Section describes the following adjustments:

- **Welding force** to the values required by the specific application.
- **Down speed** of the electrodes approaching the parts.
- Eliminating any **down stop** settings.

CAUTION: Excessive force can damage the electrodes and/or the workpiece.

The air-actuated weld heads are supplied with *EZ-AIR*, a pneumatic control that actuates the electrodes and maintains a preset firing force. At a predetermined firing force, *EZ-AIR* automatically closes the inlet and outlet valves to the weld head actuation cylinder and eliminates over-force.


Down speed and welding force are the only two adjustments to be made when setting up the *EZ AIR*. Down stops are *not* required.

NOTE: *Before* performing the following instructions, get the separate *EZ-AIR* Operator Manual supplied with the weld head and follow the detailed procedures for operating and adjusting *EZ-AIR*.

- 1 Start with the **right** side of the head.
- 2 Use the force adjustment knob to set the weld head force indicator to "4." The indicator is located on the front of the force tube just below the force adjustment knob.

- 3 Place an Amada Weld Tech Force Gauge beneath the electrode, as shown. The force gauge **must** be supported on the **bottom** for proper indication of force.

Depress and hold the footswitch. Note the force indication on the force gauge. When the head firing switch "clicks" (closes), the force will stabilize. If the firing switch does not close, or the force keeps increasing, verify that all of the connections have been properly made per the instructions in the *EZ-AIR* manual.



- 4 Cycle the electrode up and down several times and adjust the down speed by turning the right hand knob that is located on the back of the *EZ AIR*. The down speed should be adjusted to provide a comfortable speed for the operator or automation without excessive impact force to the parts.

CHAPTER 3: OPERATING INSTRUCTIONS

- 5 The force gauge will indicate the electrode force. Use the force adjustment knob to increase the indicated force if the initial force reading is less than the required force setting for the welding application. If the initial force reading is greater than the required force setting, decrease the indicated force.
- 6 Set the down speed and welding force on the *left* side of the head repeating steps 2 through 5.
- 7 After setting each electrode force, particularly in automated applications, remove the force adjustment knobs by loosening the two set screws that secure them to the shafts. Invert the knobs and place them on the shafts. Be sure to insert the locking tabs on the knobs into the slots on the force tubes. Re-tighten the set screws. If necessary, re-adjust the electrodes in their holders to accommodate the workpiece. The faces of both electrodes should be in the same plane and the gap (spacing) between the electrodes should be uniform.
- 8 A down stop is never required when using *EZ-AIR*. Turn the down stop screws counter-clockwise to their fullest extension without actually disengaging them. This will allow maximum downward travel of the upper arms.

Section III. Model TL-088B-F/M Manually-Actuated Head Setup

This Section describes the following adjustments:

- **Firing force** to the value required by the specific application;
- **Maximum force** the electrodes can exert on the workpiece during the welding cycle
- **Down stroke** limits.

CAUTION: Excessive force can damage the electrodes and/or the workpiece.

- 1 Start with the **right** side of the head. Do **not** connect the DFS/88 switchbox at this time. Connect the right side firing switch cable to the power supply firing switch connector. Use the force adjustment knob to set the weld head force indicator to "4". Indicator is located on the front of the force tube just below the force adjustment knob.
- 2 If the application is a welding application, adjust the spacing so that an Amada Weld Tech Force Gauge fits between the right electrode and a workpiece.
- 3 Depress and hold the pedal. Note the force indication on the force gauge when the head firing switch "clicks." If the firing switch closure is inaudible, it is easily detected by observing the firing switch indicator on the welding power supply (control). For older, or non-Amada Weld Tech Power Supplies, an ohmmeter or continuity checker can be connected to the pins on the firing switch connector.
- 4 Use the force gauge reading from the previous step as a starting point. Use the force adjustment knob to **increase** the indicated force if the initial force reading is **less than** the required force setting. If the initial force reading is **greater than** the required force setting, **decrease** the indicated force.
- 5 Repeat steps 1 through 4 to set the firing force on the **left** side of the head. Disconnect the power supply firing switch connector from the right side firing switch cable and connect to the left side firing switch cable.
- 6 Depress and release the footpedal. Verify that the force applied by the operator does not exceed the force required to close the firing switch by more than five percent (5%).
- 7 After setting the required force, remove the force adjustment knob by loosening the two set screws which secure it to the shaft. Invert the knob and place it on the shaft. Be sure to insert the locking tab on the knob into the slot on the force tube. Re-tighten both set screws.
- 8 Reconnect the DFS/88 to both the right/left side firing cables and attach to the power supply firing switch connector.

CHAPTER 3: OPERATING INSTRUCTIONS

- 9 If necessary, re-adjust the electrodes in their holders to accommodate the workpiece. The faces of both electrodes should be in the same plane and the gap (spacing) between the electrodes should be uniform.
- 10 Turn the downstop screws counter-clockwise to their fullest extension without actually disengaging them. This will allow maximum downward travel of the upper arms. The following downstop adjustments should be made *only* if the workpiece would be damaged if the upper arms travel too far. ***In most applications, use of the downstop is not recommended.***
- 11 Start with the right downstop. Place the workpiece in the appropriate position. Rotate the downstop screw clockwise until the electrode no longer contacts the workpiece. Check the adjustment by depressing and releasing the footpedal.
 - A) Depress and ***hold*** the footpedal.
 - B) Slowly rotate the downstop counter-clockwise until the force firing switch in the head closes. Rotate the downstop one or two additional turns counter-clockwise.
 - C) The additional turn(s) will allow for electrode wear and/or the slight variations of the position of the electrode in its holder.
 - D) Re-check that the firing switch consistently closes.
- 12 Repeat this procedure for the left downstop.

CAUTION: Do *not* attempt to use the downstop adjustments to limit the force which is applied to the workpiece. This will result in inconsistent welds.

Section IV. Model TL-080B-F/M (and legacy models 84MF and 86MF) Manually-Actuated Head Setup

This Section describes the following adjustments:


- **Firing force** to the value required by the specific application.
- **Maximum force** the electrodes can exert on the workpiece during the welding cycle.
- **Down stroke** limits.

CAUTION: Excessive force can damage the electrodes and/or the workpiece.

Use the force adjustment knob to set the weld head force indicator to "4". Indicator is located on the front of the force tube just below the force adjustment knob. Set heads with digital readouts to "100".

If the application is a welding application, adjust the electrode spacing so that an Amada Weld Tech Force Gauge fits between the electrodes, as illustrated.

Depress and hold the footpedal. Note the force indication on the force gauge when the head firing switch "clicks." If the firing switch closure is inaudible, it is easily detected by observing the firing switch indicator on the welding power supply (control). For older, or non-Amada Weld Tech Power Supplies, an ohmmeter or continuity checker can be connected to the pins on the firing switch connector.



Use the force gauge reading from the previous step as a starting point. Use the force adjustment knob to **increase** the indicated force if the initial force reading is **less than** the required force setting. If the initial force reading is **greater than** the required force setting, **decrease** the indicated force.

Depress and release the footpedal. Verify that the force applied by the operator does not exceed the force required to close the firing switch by more than five percent (5%).

After setting the required force, remove the force adjustment knob by loosening the two set screws which secure it to the shaft. Invert the knob and place it on the shaft. Be sure to insert the locking tab on the knob into the slot on the force tube. Re-tighten both set screws.

CHAPTER 3: OPERATING INSTRUCTIONS

If necessary, re-adjust the electrodes (thermode) in their holders to accommodate the workpiece.

Turn the downstop screw counter-clockwise to its fullest extension without actually disengaging it. This will allow maximum downward travel of the upper arm. The following downstop adjustment should be made **only** if the workpiece would be damaged if the upper arm travels too far. ***In most applications, use of the downstop is not recommended.***

- A) Place the workpiece in the appropriate position. Rotate the downstop screw clockwise until the electrode(s) or thermode no longer contacts the workpiece. Check the adjustment by depressing and releasing the footpedal.
- B) Depress and ***hold*** the footpedal. Slowly rotate the downstop counter-clockwise until the force firing switch in the head closes. Rotate the downstop one or two additional turns counter-clockwise. The additional turn(s) will allow for electrode wear and/or the slight variations of the position of the electrode (thermode) in its holder. Re-check that the firing switch consistently closes.

CAUTION: Do ***not*** attempt to use the downstop adjustment to limit the force which is applied to the workpiece. This will result in inconsistent welds (reflow soldering).

Section V. Legacy Models 80MA-EZ, 84MA-EZ, and 86MA-EZ Air Actuated Head Setup

This Section describes the following adjustments:

- **Welding force** to the value required by the specific application.
- **Down speed** of the electrode approaching the parts.
- Eliminating any **down stop** setting.

CAUTION: Excessive force can damage the electrodes and/or the workpiece.


The air-actuated weld heads are supplied with *EZ-AIR*, a pneumatic control that actuates the electrodes and maintains a preset firing force. At a predetermined firing force, *EZ-AIR* automatically closes the inlet and outlet valves to the weld head actuation cylinder and eliminates over-force.

Down speed and welding force are the only two adjustments to be made when setting up the *EZ AIR*. Down stops are **not** required.

NOTE: *Before* performing the following instructions, get the separate *EZ-AIR* Operator Manual supplied with the weld head and follow the detailed procedures for operating and adjusting *EZ-AIR*.

- 1 Use the force adjustment knob to set the weld head force indicator to "4." The indicator is located on the front of the force tube, just below the force adjustment knob. Set heads with digital readouts to "100."
- 2 If electrodes are being used, adjust the electrode spacing so that an Amada Weld Tech Force Gauge fits between the electrodes, as shown.

Depress and hold the footswitch. Note the force indication on the force gauge. When the head firing switch "clicks" (closes), the force will stabilize. If the firing switch does not close, or the force keeps increasing, verify that all of the connections have been properly made as described in the *EZ-AIR* manual.



- 3 Cycle the electrode up and down several times and adjust the down speed by turning the knob that is located on the back of the *EZ AIR* kit. The down speed should be adjusted to provide a comfortable speed for the operator or automation without excessive impact force to the parts.

CHAPTER 3: OPERATING INSTRUCTIONS

- 4 The force gauge will indicate the electrode force. Use the force adjustment knob to increase the indicated force if the initial force reading is less than the required force setting for the welding application. If the initial force reading is greater than the required force setting, decrease the indicated force.
- 5 After setting the required force, particularly in automated applications, remove the force adjustment knob by loosening the two set screws, which secure it to the shaft. Invert the knob and place it on the shaft. Be sure to insert the locking tab on the knob into the slot on the force tube. Re-tighten both set screws.
- 6 If necessary, re-adjust the electrodes in their holders to accommodate the work piece.
- 7 A down stop is never required when using *EZ-AIR*. Turn the down stop screws counter-clockwise to their fullest extension without actually disengaging them. This will allow maximum downward travel of the upper arms.

CHAPTER 4

USER MAINTENANCE

Section I. General Maintenance

Inspection

Clean all electrical connections every six months to minimize welding circuit resistance. Inspect all bearings and braces for excessive wear every three years and replace as necessary.

Lubrication

All bearing surfaces are designed for non-lubricated operation. Do **not** oil any bearings or sleeves **except** for the use of a dry lubricant on weld heads used in automated, air actuated systems.

Section II. Standard Resistance Welding Electrode Cleaning

- 1 Re-surface tips periodically to remove oxides and welding debris from the electrodes.
- 2 Set the **WELD/NO WELD** Switch on the welding power supply, or control, to the **NO WELD** position.
- 3 Clean the electrodes using 400 to 600 grit emery paper. Fold the emery paper over a *flat, rigid backing* with the grit surface facing out. The rigid backing will maintain the "flatness" of the electrode face during cleaning.
- 4 Place emery paper and backing between electrodes. If the head is air actuated, reduce the pressure on the top of the cylinder. Actuate the head. The electrodes should contact with the paper with a force which is low enough to allow the paper to be moved without damaging its surface. Move the paper in a circular motion while maintaining the contact force.
- 5 Wipe the electrodes so that they are clean.


Section III. Unitip Electrode Maintenance

To ensure the best possible welds, new Unitip electrodes must be cleaned (or "dressed") before they are first used. This ensures that the electrode tip is flat, which is necessary to make maximum contact with the workpiece surface.

During normal welding operations, oxides build up as a natural result of the welding process. Oxide buildup limits the flow of current to the workpieces, so Unitips must be cleaned periodically. If the electrode starts to stick to the workpiece, the electrode has become dirty and needs to be cleaned.

CAUTION: The small size of the Unitip makes the electrode tip *extremely susceptible to damage* during cleaning. *Never apply a force greater than 100 grams (3 ounces)* when cleaning, because the Ceramic Polishing Squares (Model CPD) have a hard surface which can cause the two halves of the electrode to split away from the insulator.

- 1 If necessary, install the Unitip in an electrode holder. Adjust the surface height of the work holder so that it is at the same level as the workpiece surface.
- 2 Place a polishing square on the work holder surface, directly beneath the tip of the electrode.



- 3 Bring the electrode tip into contact with the polishing square by applying a force *less than 100 grams (3 ounces)*. Gently pull the polishing disk forward, *keeping the direction of pull in a straight line parallel to the insulator as shown above*. Do *not* move the polishing square from side-to-side, or from front-to-back, or the two halves of the electrode will split away from the insulator.
- 4 After using the polishing square, clean the electrode tip with a small cotton swab saturated in alcohol.
- 5 Examine the electrode tip with a small mirror for flatness and direction of surface scratches. A properly dressed Unitip will have small scratch marks parallel to the insulator.


Section IV. Tare Spring Adjustment

Model TL-080B, TL-088B

(and legacy model 86M)

The tare spring adjustment compensates for the varying mass of different upper electrodes and adapters

- 1 With the head in a vertical position and the upper arm and electrodes installed, set the force adjustment to ***minimum*** by turning the firing force adjustment knob fully counterclockwise.
- 2 Hold a measuring scale beside the upper electrode adapter block, grasp the block, and move the block up and down between the tare spring travel limits. The total travel will be about 3.2 mm (1/8 inch). Push the block down against the bottom limit, then gently release it. The tare spring should exert enough force to return the electrode to the center of its travel, approximately 1.6mm (1/16 inch) from either extreme. If the electrode block does not re-center, adjust the tare spring.
- 3 If necessary, adjust the tare spring tension adjustment screw setting with a 3.2mm (1/8 inch) Allen wrench. The adjustment screw is recessed in the center of the tare spring assembly at the bottom of the force spring tube.
- 4 Adjust the screw until the electrode block centers itself after being depressed and released. Tightening the screw increases tare spring tension, which increases the upward force on the upper electrode assembly. If the upper electrode interconnecting flexure interferes with the adjustment procedure, temporarily disconnect it from the upper electrode adapter block.
- 5 After adjusting the tare spring tension, recheck the firing force adjustment and readjust if required.



APPENDIX A.

Technical Specifications

Low-Force Weld Heads: 2.2 to 89N (0.25 to 20 Lbs)

FEATURES		TL-080B-F/M (1)	TL-088B-F/M
Production Status		Active Model	Active Model
Actuation		Manual	Manual
Weld Force	Max. N (lbs)	0.5 (2.2)	0.5 (2.2)
	Min. N (lbs)	20 (89)	20 (89)
Maximum Rating	(KVA)	2	5
	(watt-seconds)	250	250
Electrode Stroke	mm	25	25
	(inch)	(1.0)	(1.0)
Electrode Diameter	mm	3.2	6.2
	(inch)	(1/8)	(0.245)
Electrode Holder Type		Offset	Series
Max. Throat Size	mm	49 x 152	157 x 159
	(inch)	(1.94 x 6.0)	(6.2 x 6.25)
Maximum Distance between Electrodes	mm	-	44.5
	(inch)	-	(0.75)
Electrode Series		ES-0400	ES-0800E
Weld Cable Size:	(AWG)	#2	#2/0
	Length: cm (inch)	28 (11)	28 (11)
Foot Pedal Model Number		CP	MSP
Air Solenoid Voltage (VAC)		-	-
Air Pressure for Max. Force kPa (psi)		-	-
Cylinder Inside Diameter mm (inch)		-	-
Cycle Rate (full strokes/sec) at Min. Force at greater than 20% of Rated Force		-	-
Max. Dimensions:	Height: mm (inch)	348 (13.7)	429 (16.7)
	Width: mm (inch)	193 (7.6)	343 (13.5)
	Depth: mm (inch)	43 (1.7)	102 (4.0)
Weight kg (Lbs)		2.3 (5)	6.4 (14)

APPENDIX A. TECHNICAL SPECIFICATIONS

Low-Force *EZ-AIR* Weld Heads: 2.2 to 89N (0.25 to 20 Lbs)

FEATURES	80MA-EZ-000	86MA-EZ-000 (2)	TL-088B-MA-EZ
Production Status	Legacy Model	Legacy Model	Active Model
Actuation	Air	Air	Air
Weld Force: Max. N (lbs) Min. N (lbs)	89 (20) 4.4 (1.0)	89 (20) 4.4 (1.0)	89 (20) 4.4 (1.0)
Maximum Rating: (KVA) (watt-seconds)	2 250	1 125	5 250
Electrode Stroke: mm (inch)	25 1	1 25	1 25
Electrode Diameter mm (inch)	1/8 3.2	Unibond	0.245 6.2
Electrode Holder Type	Offset	Parallel Gap	Series
Max. Throat Size mm Height x Depth (inch)	49 x 152 1.94 x 6.0	86 x 132 3.38 x 5.2	157 x 159 6.2 x 6.25
Maximum Distance mm between Electrodes (inch)	- -	1.0 0.040	44.5 0.75
Electrode Series	ES-0400	EU or UT	ES-0800E
Weld Cable Size: Length: (AWG) cm (inch)	#2 28 (11)	#2 28 (11)	#2/0 28 (11)
Foot Pedal Model Number	-	-	-
Valve Driver Input (VAC)	24	24	24
Air Pressure for Max. Force [Unlubricated Air] kPa (psi)	896 130	896 130	896 130
Cylinder Inside Diameter (inch/mm)	18.9 (.75)	18.9 (.75)	18.9 (.75)
Cycle Rate (full strokes/sec) at Min. Force at greater than 20% of Rated Force	2.5 1	2.5 1	2.5 1
Max. Dimensions: Height mm (inch) Width mm (inch) Depth mm (inch)	404 (15.9) 338 (13.3) 87 (3.4)	406 (16.0) 338 (13.3) 87 (3.4)	490 (19.3) 396 (15.6) 142 (5.6)
Weight kg (lbs)	4.3 9.4	4.3 9.4	9.9 21.8

APPENDIX A. TECHNICAL SPECIFICATIONS

High-Force Weld Heads: 18 to 178N (4 to 40 Lbs)

FEATURES		84MF
Production Status		Legacy Model
Actuation		Manual
Weld Force	Max. N (lbs) Min. N (lbs)	178 (40) 18 (4)
Maximum Rating	(KVA) (watt-seconds)	5 250
Electrode Stroke	mm (inch)	25 1
Electrode Diameter	mm (inch)	6.4 (1/4)
Electrode Holder Type		Offset
Max. Throat Size	mm	84 x 155
Height x Width	(inch)	3.3 x 6.1
Maximum Distance between Electrodes	mm (inch)	- -
Electrode Series		ES-0800
Weld Cable Size	(AWG)	#2/0
Length	mm (inch)	28 (11)
Foot Pedal Model Number		MSP
Air Solenoid Voltage	(VAC)	-
Air Pressure for Max. Force	kPa	-
[Unlubricated Air]	(psi)	-
Cylinder Inside Diameter	mm (inch)	-
Cycle Rate (full strokes/sec)	At Min. Force At greater than 20% of Rated Force	- -
Max. Dimensions:	Height mm (inch) Width mm (inch) Depth mm (inch)	424 (16.7) 254 (10.0) 66 (2.6)
Weight	kg (lbs)	3.6 8

TL-080B METRIC THIN-LINE™ WELD HEADS

APPENDIX A. TECHNICAL SPECIFICATIONS

High-Force *EZ-AIR* Weld Heads: 18 to 178N (4 to 40 Lbs)

FEATURES		84MA/EZ
Production Status		Legacy Model
Actuation		Air
Weld Force:	Max. N (lbs)	178 (40)
	Min. N (lbs)	17.8 (4)
Maximum Rating:	(KVA)	5
	(watt-seconds)	250
Electrode Stroke:	mm	25
	(inch)	1
Electrode Diameter	mm	6.4
	(inch)	1/4
Electrode Holder Type		Offset
Max. Throat Size	mm	7.8 (3.3)
	Height x Depth (inch)	198 (84)
Maximum Distance between Electrodes	mm	-
	(inch)	-
Electrode Series		ES-0800
Weld Cable Size:	(AWG)	#2/0
	Length: cm (inch)	28 (11)
Foot Pedal Model Number		-
Valve Driver Input (VAC)		24
Air Pressure for Max. Force [Unlubricated Air]	kPa	896
	(psi)	130
Cylinder Inside Diameter (inch/mm)		1.0625
Cycle Rate (full strokes/sec) at Min. Force at greater than 20% of Rated Force		1
		2.5
Max. Dimensions:	Height mm (inch)	514 (20.25)
	Width mm (inch)	395 (15.55)
	Depth mm (inch)	117 (4.6)
Weight	kg	12.4
	(lbs)	5.62

AMADA WELD TECH INC.

<http://www.amadaweldtech.com>

AMADA WELD TECH INC.

1820 South Myrtle Ave., Monrovia, CA 91016, U.S.A.

TEL. +1-626-303-5676 FAX, +1-626-358-8048

<http://www.amadaweldtech.com>

AMADA WELD TECH CO., LTD.

200, Ishida, Isehara-shi, Kanagawa 259-1196, Japan

AMADA WELD TECH KOREA CO., LTD.

28, Dongtanhana 1-gil, Hwaseong-si, Gyeonggi-do, 18423, Korea

TEL. +82-31-8015-6810 FAX. +82-31-8003-5995

AMADA WELD TECH SHANGHAI CO., LTD.

Unit 401, A206(C8), No. 77, Hongcao Road, Xuhui District, Shanghai, China

TEL. +86-21-6448-6000 FAX. +86-21-6448-6550

AMADA WELD TECH GmbH

Lindberghstrasse 1, DE-82178 Puchheim, Germany

TEL. +49-89-839403-0 FAX. +49-89-839403-68

AMADA WELD TECH TAIWAN CO., LTD.

Rm. 5, 2F., No. 9, Dehui St., Zhongshan Dist., Taipei 10461, Taiwan (R.O.C.)

TEL. +886-2-2585-0161 FAX. +886-2-2585-0162

AMADA VIETNAM CO., LTD.

469 Ha Huy Tap Road, Yen Vien, Gia Lam, Ha Noi, Vietnam

TEL. +84-4-6261-4583 FAX. +84-4-6261-4584

AMADA (THAILAND) CO., LTD.

Asia Industrial Estate Suvarnabhumi (AIES) 88/41 Moo 4, Khlongsuan, Bangbo, Samutprakarn 10560, Thailand

TEL. +66 2170-5900 FAX. +66 2170-5909

AMADA WELD TECH INDIA PVT. LTD.

G-A Ground Floor, 5C-409, 5th Cross, Kammanahalli Main Road, HRBR Layout, Kalyan Nagar, Bengaluru, - 560043, India

TEL. +91-80-4092-1749 FAX. +91-80-4091-0592

AMADA WELD TECH LTDA.

Av. Tamboré, 965/973, Salas P22e F11, bairro Tamboré, 06460-000-Barueri-SP, Brazil

TEL. +55-11-4193-1187

AMADA WELD TECH INC.

1820 South Myrtle Ave., Monrovia, CA 91016, U.S.A.

TEL. +1-626-303-5676 FAX. +1-626-358-8048